


# Example of connection for Multicontrol with substation(US) (with intelligent )



For a faultless function you must connect all wire !